


MESTRA®

SOPORTE FRESADOR - PARALELÓMETRO V3
MILLING SUPPORT - V3 PARALLELOMETER
SUPPORT MACHINE A FRAISER - PARALLELOMETRE V3
R-080410



MESTRA®

SOPORTE FRESADOR - PARALELOMETRO V3
MILLING SUPPORT - V3 PARALLELOMETER
 SUPPORT MACHINE A FRAISER - PARALLELOMETRE V3
 R-080410

Nº	Ref.	Descripción	Description	Nº	Ref.	Descripción	Description
1	080410-01	Base	Base	33	080410-33	Bielas de articulación	Articulation connection rod
2	080410-02	Base porta modelos	Model holder base	35	080410-35	Manilla de bloqueo micromotor	Locking handle
3	080410-03	Varilla bloqueo	Locking bar	36	080410-36	Porta micromotor	Milling clip
4	080410-04	Manilla bloqueo	Locking handle	37	080410-37	Tornillo porta motor pavonado	Motor holder screw
5	080410-05	Muelle de rotula	Spring ball socket	38	080410-38	Porta tornillo regulación	Regulation screw holder
6	030120-03	Tornillo base y portaminas	Model holder screw	39	080410-39	Tomillo y tuerca regulación	Regulation screw and nut
7	080410-07	Casquillo de rotula	Ball socket housing	41	080410-41	Manilla de bloqueo altura	Height locking handle
8	080410-08	Casquillo de rotula roscado	Threaded ball socket housing	42	080410-42	Biola de elevación	Elevation connection rod
9	080410-09	Rotula de soporte	Ball socket	43	080410-43	Porta tornillo regulación	Regulation screw holder
10	080410-10	Tuerca fija rotula	Ball socket nut	44	080410-44	Tornillo porta articulación	Articulation holder screw
11	080410-11	Tuerca aguja de centrado	Centering needle nut	45	050311	Lapicero completo	Complete pen
12	080410-12	Tornillo topes	Centering stop screws	46	050310-21	Tuerca de articulación	Articulation nut
13	080410-13	Mesa porta modelos	Model holder table	47	050310-20	Muelle articulaciones	Articulations spring
14	080410-14	Tornillo de centrado	Centering screw	48	050310-25	Tuerca fijación lápiz	Pen fixation nut
15	080410-15	Porta tornillo de centrado	Centering screw holder	49	050310-24	Segunda articulación	Second articulation
16	080410-16	Topes base porta modelos	Model holder base stops	50	050310-22	Primera articulación	First articulation
17	080410-17	Portaminas	Pen holder	51	080410-51	Casquillo soporte elevación	Elevation support bushing
19	080410-19	Columna central	Center column	52	080410-52	Porta brocas completo	Drill holder complete
20	080410-20	Tornillo columna central	Center column screw	53	080410-53	Casquillo micromotor 1	Micromotor bushing 1
21	080410-21	Pomos sujeción	Knobs	54	080410-54	Casquillo micromotor 2	Micromotor bushing 2
22	080410-22	SopORTE árboles	Tree support	55	080410-55	Casquillo micromotor 3	Micromotor bushing 3
23	080410-23	Varilla columna central	Center column bar	56	080410-56	Casquillo micromotor 4	Micromotor bushing 4
24	080410-24	Casquillo plástico árbol giratorio	Rolling tree plastic housing	57	080410-57	Casquillo micromotor 5	Micromotor bushing 5
25	080410-25	Arandela árbol giratorio	Rolling tree washer	58	050310-30	Ala punta recta varilla	Straight point
26	080410-26	Varilla árbol giratorio	Rolling tree bar	59	050310-32	Punta ala 0,25	0,25 point
27	080410-27	Cuerpo árbol giratorio	Rolling tree body	60	050310-33	Punta ala 0,50	0,50 point
28	080410-28	Árbol de paralelómetro	Paralelometer tree	61	050310-34	Punta ala 0,75	0,75 point
29	080410-29	Casquillo plástico pequeño	Small housing	62	080410-62	Llave Allen 3 mm	3 mm allen wrench
30	080410-30	Pieza porta articulación	Articulation piece	63	080410-63	Llave Allen 5 mm	5 mm allen wrench
31	080410-31	Tornillo con rodamiento	Roller screw	64	050310-31	Espátula paralelómetro	Paralelometer spatula
32	080410-32	Muelle de articulación	Articulation spring				