

# Work stations

**Ref. 100302**

**Ref. 080195**



# Single workbench (1 station)

Ref. 100302

Metallic structure with a top shelf and wooden countertop, equipped with armrests and a stainless steel protector.

- ✓ Storage: 2 central drawers and a right-side module with 3 lockable drawers.
- ✓ Suction: Integrated 500 W adjustable suction unit with an independent activation switch and rotary power dial.
- ✓ Compressed Air: Air blow gun with an integrated pressure gauge.
- ✓ Control panel: 3 independent switches for suction, lighting, and two power outlets.
- ✓ Lighting & Accessories: Includes a high-intensity 162-LED lamp with an articulated arm and 4 plastic work trays.
- ✓ Pre-installed connection for gas burners.



## Characteristics

Table height: 850 mm	Shelf height: 1070 mm
Width: 1220 mm	Depth: 600 mm
Packaging dimensions: 134 x 73 x 120 cm	
Net weight: 130 kg	Gross weight: 150 kg

Workstation specifically designed to meet the demands of trimming, finishing, and polishing. Features an enameled steel structure combined with a high-quality wooden countertop. A spacious, robust, and perfectly illuminated station for precise and comfortable work. Includes the RENHE 119 carbon brush handpiece.

## SUCTION SYSTEM

The station incorporates a dual suction system (upper and lower), designed to maintain a clean and healthy working environment:

- ✓ Suction activation: Independent or synchronized with the handpiece.
- ✓ Power regulation: Adjusted via a rotary control knob
- ✓ Dual filtration: Easy-access system for quick and simple maintenance.
- ✓ Versatility: Includes plugs to seal off the upper or lower suction inlets as needed.

## CONTROL PANEL AND EQUIPMENT

- ✓ Main power switch and independent lighting switch..
- ✓ Foot pedal for handpiece and suction activation.
- ✓ Micromotor panel with speed control and change of handpiece rotation direction.
- ✓ Integrated socket for additional laboratory accessories.
- ✓ Compressed air gun with an integrated pressure gauge

## ERGONOMICS AND STORAGE

- ✓ Wooden bench pin with adjustable angle for improved ergonomic posture.
- ✓ Organization: Two central drawers and one lateral drawer for efficient storage.
- ✓ Flexible magnifying lens for detailed visual tasks.
- ✓ Protection: Two polycarbonate safety shields for the bench pin area



## Characteristics

Height: 1240 mm	Width: 750 mm	Depth: 550 mm
Packaging dimensions: 86 x 70 x 140 cm	Net weight: 70 kg	
Gross weight: 80 kg	Power: 500 W	Voltage: 220 V
Suction: 172 m <sup>3</sup> /h	Noise level: 68 dB	Micromotor power: 40 W

## Handpiece RENHE 119

Speed: 35.000 rpm	Power: 65 W
Torque: 2,8 n-cm	Handpiece weight: 200 g (wire not included)
Plier: Ø 2,35 mm	



At **MESTRA** we are specialized in the manufacture and distribution of dental machinery and appliances. We are a Spanish company based in Bizkaia. We currently export to clients in more than fifty countries on five continents and we have more than a thousand references in our catalogue.

We have maintained a line of constant expansion since our foundation in 1945, thanks to our best qualities: the high quality of our products that have earned the ISO 9001:2015 certification by TÜV Rheinland, a close and attentive relationship with our customers, and a constant technical innovation in the design of our products.

Our design philosophy is based on three fundamental pillars: the needs of our clients, the observation of the techniques used in dental laboratories and our more than 77 years of experience providing creative and contemporary solutions to the daily problems of professionals in the sector.

**Do you want to take a virtual visit to our training and exhibition center?**

**Contact us and we'll show you!**



**Talleres Mestraitua SL**  
(+34) 944 530 388  
info@mestra.es - www.mestra.es  
48150 SONDIKA (Spain)

